




Notes for flying hardware (cradle)

1-910-165 / 1-910-166


load adapter for mounting with clamp (optional)



ILS 64
VLS 64

**use either shackle
or
load adapter**

load adapter for mounting with clamp (optional)



ICS 2
ICS 4
ICS 5
VLX 2
VLX 4